

# HIOKI

DC HIGH VOLTAGE PROBE P2000

NEW

NWI Instrumentation

*World's First*  
**CAT III**  
**2000 V**



## Safe Inspection of Photovoltaic Power Generation Facilities with Increasingly High Voltage

Photovoltaic power generation equipment are becoming increasingly high-voltage in order to reduce costs and improve the efficiency of power generation systems. As a result, it is important to select measuring instruments that support higher voltage measurement to protect the safety of inspection workers.

The P2000 enables high voltage measurement up to CAT III 2000 V by simply connecting to a compatible HIOKI clamp meter or digital multimeter.



CE



## P2000 Specifications

Maximum input voltage (max. rated voltage between INPUT H-INPUT L)	DC 2000 V
Maximum rated voltage to earth	2000 V (Measurement Category III) 1000 V (Measurement Category IV)
Input resistance	20 MΩ ±1.0% (between INPUT H – INPUT L)
Output ratio	Depends on the input impedance of the connected device (example: 1/10 when a device with an input impedance of 10 MΩ is connected)
Overload protection	DC/AC 2200 V 1 minutes (between INPUT H – INPUT L) DC/AC 600 V 1 minutes (between OUTPUT H – OUTPUT L)
Secondary terminal	4 mm banana terminal
Operating environment	Indoor use, pollution degree 2, altitude up to 2000 m
Operating temperature and humidity range	Temperature: -25°C to 65°C Humidity: -25°C to 40°C, up to 80% RH (non-condensing) 40°C to 65°C, (the operation humidity limit falls linearly from 40°C 80% RH to 65°C 25% RH, given that there is no condensation)
Storage temperature and humidity range	-30°C to 70°C 90% RH or less (non-condensing)
Applicable standards	Safety EN 61010

Product warranty period	3 years (probe body and cable part are not covered by warranty)
Accessories	L4943 connection cable, Strap belt, Strap buckle x2, C0205 carrying case, "Instruction Manual", "Usage Precautions"

### Accuracy in combination with the DT4261 or CM series

Models	Combination Accuracy Specifications (Representative value)
DT4261	±0.5% rdg. ±5 dgt.
CM4375-50	
CM4373-50	
CM4371-50	
CM4141-50	

## Model

Model : AC HIGH VOLTAGE PROBE P2000

Model No. (Order Code) ..... P2000

## P2000 Compatible Models



DIGITAL MULTIMETER  
DT4261



AC/DC CLAMP METER  
CM4375-50



AC/DC CLAMP METER  
CM4373-50



AC/DC CLAMP METER  
CM4371-50



AC CLAMP METER  
CM4141-50

# HIOKI

HIOKI E. E. CORPORATION

### HEADQUARTERS

81 Koizumi,  
Ueda, Nagano 386-1192 Japan

<https://www.hioki.com/>



Scan for all regional contact information

DISTRIBUTED BY



NWI GROUP PTY LTD

UNIT 1/88 MAGOWAR ROAD  
GIRRAWEE NSW 2145

INFO@NWIGROUP.COM.AU  
1300 669 162